

A06B-6066-H246	AC Digital servo amp
A06B-6066-H266	AC Digital Servo Amp
A06B-6066-H281	AC Digital servo amp
A06B-6066-H291	AC Digital servo amp
A06B-6071-H115	Alpha Servo Amp
A06B-6071-H122	Alpha Servo Amp
A06B-6071-H126	Alpha Servo Amp
A06B-6071-H201	Alpha Servo Amp
A06B-6073-H004	Alpha Servo Amp
A06B-6073-H034	Alpha Servo Amp
A06B-6073-H044	Alpha Servo Amp
A06B-6073-H104	Alpha Servo Amp
A06B-6073-H106	Alpha Servo Amp
A06B-6073-H144	Alpha Servo Amp
A06B-6073-H146	Alpha Servo Amp
A06B-6073-H166	Alpha Servo Amp
A06B-6077-H106	Power Supply
A06B-6077-H111	Power Supply
A06B-6077-H115	Power Supply
A06B-6077-H126	Power Supply
A06B-6077-H130	Power Supply
A06B-6078-H206	Spindle Module
A06B-6078-H211	Spindle Module
A06B-6078-H230	Spindle Module
A06B-6078-H306	Spindle Module
A06B-6078-H411	Spindle Module
A06B-6078-H415	Spindle Module
A06B-6079-H101	Alpha Servo Amp
A06B-6079-H102	Alpha Servo Amp
A06B-6079-H103	Servo Module
A06B-6079-H104	Servo Module
A06B-6079-H105	Servo Module
A06B-6079-H106	Servo Module
A06B-6079-H107	Servo Module
A06B-6079-H108	Alpha Servo Amp
A06B-6079-H201	Servo Module
A06B-6079-H202	Servo Module
A06B-6079-H203	Servo Module
A06B-6079-H204	Servo Module
A06B-6079-H205	Alpha Servo Amp
A06B-6079-H206	Servo Module
A06B-6079-H207	Servo Module
A06B-6079-H208	Servo Module
A06B-6079-H209	Servo Module
A06B-6079-H210	Servo Module
A06B-6079-H301	Alpha Servo Amp

A06B-6079-H302	Alpha Servo Amp
A06B-6079-H303	Alpha Servo Amp
A06B-6079-H304	Alpha Servo Amp
A06B-6079-H305	Alpha Servo Amp
A06B-6079-H306	Alpha Servo Amp
A06B-6079-H307	Alpha Servo Amp
A06B-6079-H401	Alpha Servo Amp
A06B-6079-H713	Alpha Servo Amp
A06B-6080-H301	Alpha Servo Amp
A06B-6080-H302	Alpha Servo Amp
A06B-6080-H303	Alpha Servo Amp
A06B-6080-H304	Alpha Servo Amp
A06B-6080-H305	Servo Module
A06B-6080-H306	Alpha Servo Amp
A06B-6080-H307	Alpha Servo Amp
A06B-6081-H103	Alpha Power Supply
A06B-6081-H106	Alpha Power Supply
A06B-6082-H206	Spindle Module
A06B-6083-H130	Alpha Power Supply
A06B-6083-H230	Alpha Power Supply
A06B-6085-H205	Alpha Servo Amp
A06B-6087-H115	Power Supply
A06B-6087-H126	Power Supply
A06B-6087-H130	Power Supply
A06B-6087-H137	Alpha Power Supply
A06B-6087-H145	Power Supply
A06B-6087-H155	Alpha Power Supply
A06B-6087-H326	Alpha Power Supply
A06B-6088-H215	Spindle Module
A06B-6088-H222	Spindle Module
A06B-6088-H226	
A06B-6088-H230	
A06B-6088-H245	Spindle Module
A06B-6088-H315	Spindle Module
A06B-6088-H322	Spindle Module
A06B-6088-H326	Spindle Module
A06B-6088-H326	Spindle Module
A06B-6088-H330	Spindle Module
A06B-6088-H345	Spindle Module
A06B-6088-H411	Spindle Module
A06B-6089-H101	Alpha Servo Amp
A06B-6089-H101	Servo amp
A06B-6089-H102	Alpha Servo Amp
A06B-6089-H104	Servo amp
A06B-6089-H105	Servo amp
A06B-6089-H106	Servo amp

A06B-6089-H130	Alpha Servo Amp
A06B-6089-H201	Servo amp
A06B-6089-H202	Servo amp
A06B-6089-H203	Servo amp
A06B-6089-H204	Alpha Servo Amp
A06B-6089-H205	Alpha Servo Amp
A06B-6089-H206	Servo amp
A06B-6089-H207	Servo amp
A06B-6089-H208	Servo amp
A06B-6089-H209	Servo amp
A06B-6089-H210	Servo amp
A06B-6089-H215	Alpha Servo Amp
A06B-6089-H321	Alpha Servo Amp
A06B-6089-H324	Servo amp
A06B-6090-H002	Servo amp
A06B-6090-H003	Servo amp
A06B-6090-H004	Servo amp
A06B-6090-H006	Servo amp
A06B-6090-H008	Servo amp
A06B-6090-H206	Alpha Servo Amp
A06B-6090-H222	Servo amp
A06B-6090-H223	Servo amp
A06B-6090-H224	Servo amp
A06B-6090-H233	Servo amp
A06B-6090-H234	Servo amp
A06B-6090-H236	Alpha Servo Amp
A06B-6090-H244	Servo amp
A06B-6090-H246	Servo amp
A06B-6090-H266	Alpha Servo Amp
A06B-6091-H118	Alpha Power Supply
A06B-6091-H130	Alpha Power Supply
A06B-6091-H145	Alpha Power Supply
A06B-6091-H175	Alpha Power Supply
A06B-6093-H101	Beta Servo Amp
A06B-6093-H102	Beta Servo Amp
A06B-6093-H103	Beta Servo Amp
A06B-6093-H104	Alpha Servo Amp
A06B-6093-H112	Beta Servo Amp
A06B-6093-H113	Beta Servo Amp
A06B-6093-H114	Beta Servo Amp
A06B-6093-H151	Beta Servo Amp
A06B-6093-H152	Beta Servo Amp
A06B-6093-H153	Beta Servo Amp
A06B-6093-H154	Beta Servo Amp
A06B-6096-H101	Alpha Servo Amp
A06B-6096-H102	Alpha Servo Amp

A06B-6096-H103	Alpha Servo Amp
A06B-6096-H105	Alpha Servo Amp
A06B-6096-H106	Alpha Servo Amp
A06B-6096-H107	Alpha Servo Amp
A06B-6096-H108	Alpha Servo Amp
A06B-6096-H116	Alpha Servo Amp
A06B-6096-H121	Alpha Servo Amp
A06B-6096-H122	Alpha Servo Amp
A06B-6096-H201	Alpha Servo Amp
A06B-6096-H202	Alpha Servo Amp
A06B-6096-H203	Alpha Servo Amp
A06B-6096-H204	Alpha Servo Amp
A06B-6096-H205	Alpha Servo Amp
A06B-6096-H206	Alpha Servo Amp
A06B-6096-H207	Alpha Servo Amp
A06B-6096-H208	Alpha Servo Amp
A06B-6096-H209	Alpha Servo Amp
A06B-6096-H301	Alpha Servo Amp
A06B-6096-H302	Alpha Servo Amp
A06B-6096-H303	Alpha Servo Amp
A06B-6096-H304	Alpha Servo Amp
A06B-6096-H305	Servo amp
A06B-6096-H306	Alpha Servo Amp
A06B-6096-H307	Alpha Servo Amp
A06B-6097-H203	Alpha Servo Amp
A06B-6097-H206	Alpha Servo Amp
A06B-6098-H001	Alpha Servo Amp

A16B-0150-0480	5 CNTRL PCB
A16B-0150-0490	5 CNTRL PCB
A16B-0160-0030	2000/3000 PCB
A16B-0160-0210	2000 MEMORY PCB
A16B-0160-0260	2000/3000 PCB
A16B-0160-0270	2000/3000 PCB
A16B-0160-0440	2000/3000 PCB
A16B-0160-0470	2000/3000 CNTRL PCB
A16B-0160-0471	2000/3000 CNTRL PCB
A16B-0160-0481	2000/3000 PCB
A16B-0160-0540	2000/3000 CNTRL PCB
A16B-0160-0542	2000/3000 CNTRL PCB
A16B-0160-0543	2000/3000 PCB
A16B-0160-0650	2000/3000 PCB

A16B-0160-0651	2000/3000 PCB
A16B-0170-0060	2000/3000 PCB
A16B-0170-0280	2000/3000 PCB
A16B-0170-0400	5 CNTRL PCB
A16B-0190-0010	3000 CNTRL PCB
A16B-0190-0030	2000/3000 PCB
A16B-0190-0050	2000/3000 PCB
A16B-0190-0060	2000/3000 MEMORY PCB
A16B-0190-0061	2000/3000 CNTRL PCB
A16B-0190-0080	2000/3000 PCB
A16B-0190-0100	2000/3000 MEMORY PCB
A16B-0190-0101	2000/3000 PCB
A16B-0190-0800	2000/3000 PCB
A16B-1000-0010	3A MASTER CNTRL PCB
A16B-1000-0030	GB2 MASTER CNTRL PCB
A16B-1000-0070	MASTER PCB
A16B-1000-0092	FANUC PCB
A16B-1000-0100	FANUC PCB
A16B-1000-0140	RC MASTER CNTRL PCB
A16B-1000-0170	FANUC PCB
A16B-1000-0180	POWER SUPPLY UNIT
A16B-1000-0190	FANUC PCB
A16B-1010-0040	10 MASTER CNTRL PCB
A16B-1010-0041	10 MASTER CNTRL W/ FIBER OPTICS PCB
A16B-1010-0050	11 MASTER CNTRL PCB
A16B-1010-0120	MASTER CNTRL PCB
A16B-1010-0150	0 MASTER CNTRL PCB
A16B-1010-0190	10 MASTER CNTRL PCB
A16B-1010-0200	11 MASTER CNTRL PCB
A16B-1010-0210	0 MASTER CNTRL PCB
A16B-1010-0240	ZERO MATE MASTER PCB
A16B-1010-0280	0 B MASTER PCB
A16B-1010-0281	0 B MASTER PCB
A16B-1010-0285	0 MASTER CNTRL PCB
A16B-1010-0286	0 B MASTER PCB
A16B-1010-0320	10 DIGITAL MASTER PCB
A16B-1010-0321	10 MASTER CNTRL PCB
A16B-1010-0330	11 MASTER PCB
A16B-1010-0331	11 DIGITAL MASTER PCB
A16B-1100-0060	FANUC GRAPHIC PCB
A16B-1100-0080	6052 SPINDLE PCB
A16B-1100-0090	6052 SPINDLE PCB
A16B-1100-0092	6052 SPINDLE PCB
A16B-1100-0130	FANUC PCB
A16B-1100-0140	FANUC PCB

A16B-1100-0180	0 MATE E MASTER PCB
A16B-1100-0200	6059 SPINDLE DRIVE PCB
A16B-1100-0240	6059 SPINDLE PCB
A16B-1100-0241	6060 SPINDLE PCB
A16B-1100-0260	LASER INTERFACE PCB
A16B-1100-0261	6060 DRIVE PCB
A16B-1100-0280	6058-3AXIS O/S DRIVE PCB
A16B-1100-0300	6058 DRIVE PCB
A16B-1100-0310	15A BACKPLANE
A16B-1100-0330	6058-3AXIS N/S DRIVE PCB
A16B-1100-0351	SPINDLE PCB
A16B-1100-0600	FANUC PCB
A16B-1100-0800	FANUC PCB
A16B-1200-0150	6 CNTRL ROM PCB
A16B-1200-0160	6 CONTROL ADD AXES
A16B-1200-0170	6 CNTRL GRAPHIC PUNCH PCB
A16B-1200-0210	FANUC PCB
A16B-1200-0220	ADDITIONAL MEMORY PCB
A16B-1200-0230	6047-2 AXIS DRIVE PCB
A16B-1200-0270	6 CNTRL PCB
A16B-1200-0350	POWERMATE A PCB
A16B-1200-0410	ROBOT PCB
A16B-1200-0450	ROM PCB FOR 6 CONTROL
A16B-1200-0520	6050-2 AXIS DRIVE PCB
A16B-1200-0550	FANUC PCB
A16B-1200-0660	RELAY PCB
A16B-1200-0670	6057-SINGLE AXIS PCB
A16B-1200-0680	6057-2 AXIS PCB
A16B-1200-0720	6058-2 AXIS PCB
A16B-1200-0742	10 CNTRL DETECTOR PCB
A16B-1200-0800	6058-2 AXIS PCB
A16B-1200-0810	ANALOG VCU PCB
A16B-1200-0870	FANUC PCB
A16B-1200-0880	POWERMATE A SERVO PCB
A16B-1210-0020	ROBOT PCB
A16B-1210-0030	ROBOT PCB
A16B-1210-0200	ROBOT PCB
A16B-1210-0210	ROBOT PCB
A16B-1210-0220	ROBOT PCB
A16B-1210-0270	ROBOT PCB
A16B-1210-0280	ROBOT PCB
A16B-1210-0290	ROBOT PCB
A16B-1210-0300	ROBOT PCB
A16B-1210-0320	10 CNTRL DI/DO PCB
A16B-1210-0322	10 CONTROL I/O PCB
A16B-1210-0340	10 CNTRL PMC RAM PCB

A16B-1210-0350	10 CNTRL OPTION ONE PCB
A16B-1210-0360	10 CNTRL FIBER OPTIC INTERFACE
A16B-1210-0380	10 CNTRL ADD AXIS/MEM PCB
A16B-1210-0381	10 CONTROL ADDITIONAL MEMORY
A16B-1210-0410	10 CNTRL ACP PCB
A16B-1210-0430	10/11 CNTRL PCB
A16B-1210-0440	10 CNTRL ADD AXIS (R,P) PCB
A16B-1210-0460	10/11 CONTROL RES./IND. PCB
A16B-1210-0470	11 CONTROL ROM/RAM PCB
A16B-1210-0471	PMC C CASSETTE
A16B-1210-0480	11 CNTRL PCB
A16B-1210-0481	11 CNTRL PCB
A16B-1210-0506	FANUC POWER SUPPLY PCB
A16B-1210-0510	FANUC POWER SUPPLY PCB
A16B-1210-0590	O CONTROL ADDITIONAL I/O
A16B-1210-0591	O CONTROL ADDITIONAL I/O
A16B-1210-0610	10 CNTRL PC RAM BOARD PCB
A16B-1210-0620	10/11 CNTRL PIGGYBACK PCB
A16B-1210-0660	10/11 POWER SUPPLY
A16B-1210-0800	ROBOT PCB
A16B-1210-0810	PMC M CASSETTE
A16B-1210-0820	10 CNTRL PC RAM BOARD PCB
A16B-1210-0850	O CONTROL ADDITIONAL I/O
A16B-1210-0860	OPTICAL SCALE 1 PCB
A16B-1210-0940	0 CNTRL ADD 1/0 AZ PCB
A16B-1210-0950	ROBOT PCB
A16B-1210-0970	ROBOT PCB
A16B-1210-0972	FANUC PCB
A16B-1211-0030	ROBOT PCB
A16B-1211-0031	ROBOT PCB
A16B-1211-0040	2 MEGABITE ROBOT PCB
A16B-1211-0041	ROBOT PCB
A16B-1211-0042	ROBOT RAM PCB
A16B-1211-0060	ROBOT PCB
A16B-1211-0061	ROBOT PCB
A16B-1211-0062	RH ROBOT 2 AXES PCB
A16B-1211-0080	ROBOT PCB
A16B-1211-0090	ROBOT BUBBLE MEMORY PCB
A16B-1211-0091	ROBOT PCB
A16B-1211-0092	ROBOT PCB
A16B-1211-0120	ROBOT PCB
A16B-1211-0130	ROBOT PCB
A16B-1211-0170	ROBOT PCB
A16B-1211-0250	10 MA CNTRL CRT/MDI PCB

A16B-1211-0260	11 CNTRL MMC INTERFACE PCB
A16B-1211-0270	10 CNTRL AXIS CONTROL PCB
A16B-1211-0271	10/11 CONTROL AXES PCB
A16B-1211-0272	10/11 DIGITAL ADD. AXES PCB
A16B-1211-0273	10 MA CNTRL AXIS CONTROL PCB
A16B-1211-0280	11 CONTROL ROM/RAM PCB
A16B-1211-0290	10 CONTRL ROM/RAM PCB
A16B-1211-0291	10 CONTRL ROM/RAM PCB
A16B-1211-0300	0 CNTRL I/O CB PCB
A16B-1211-0301	0 CNTRL I/O C2 PCB
A16B-1211-0302	C1 I/O PCB
A16B-1211-0310	3/4 AXES DIGITAL PCB
A16B-1211-0311	3RD AXES DIGITAL PCB
A16B-1211-0340	0 CONTROL GRAPHIC/MPG PCB
A16B-1211-0520	ROBOT PCB
A16B-1211-0600	10 CNTRL PCB
A16B-1211-0750	ROBOT PCB
A16B-1211-0850	POWER SUPPLY PCB
A16B-1211-0860	ROBOT PCBPCB
A16B-1211-0870	10/11 ACP LEVEL UP PCB
A16B-1211-0890	15A POWER SUPPLY PCB
A16B-1211-0901	0 CNTRL PMC-M PCB
A16B-1211-0903	0 CNTRL PMC-M(opt) PCB
A16B-1211-0909	0 CNTRL PMC-M RAM(opt) PCB
A16B-1211-0910	0 CONTROL MMC INTERFACE PCB
A16B-1211-0920	0 CNTRL GRAPHIC/MPG PCB
A16B-1211-0930	0 C REMOTE BUFFER PCB
A16B-1211-0945	0 CONTROL D7 I/O PCB
A16B-1211-0946	0 CONTROL D6 I/O PCB
A16B-1211-0961	0 CNTRL ANALOG INT PCB
A16B-1211-0970	10/11 E3 I/O PCB
A16B-1212-0030	15-TTA CNTRL 01P62 PCB
A16B-1212-0100	POWER SUPPLY PCB
A16B-1212-0110	POWER SUPPLY PCB
A16B-1212-0130	FANUC PCB
A16B-1212-0182	PMC CASSETTE
A16B-1212-0210	0 CNTRL MEMORY PCB
A16B-1212-0215	0 C CONTROL MEMORY PCB
A16B-1212-0216	0 C 32 BIT MEMORY PCB
A16B-1212-0220	0 CONTRL I/O C7 PCB
A16B-1212-0221	0 CNTRL I/O PCB
A16B-1212-0222	0 C C5 I/O PCB
A16B-1212-0270	LASER INTERFACE PCB
A16B-1212-0300	15 A OPP. PNL. I/O PCB

A16B-1212-0470	A1 POWER SUPPLY
A16B-1212-0530	B1 POWER SUPPLY
A16B-1212-0531	16MA CNTRL POWER SUPPLY PCB
A16B-1212-0540	E STOP BRAKE PCB
A16B-1212-0870	B1 POWER SUPPLY
A16B-1212-0871	15TTB POWER SUPPLY PCB
A16B-1212-0890	LASER POWER SUPPLY PCB
A16B-1212-0901	16MA CNTRL POWER SUPPLY PCB
A16B-1212-0950	A1 POWER SUPPLY ZERO CNTRL.
A16B-1300-0100	FANUC PCB
A16B-1300-0110	ORIENTATION PCB
A16B-1300-0170	DETECTION CIRCUIT PCB
A16B-1300-0200	21 CNTRL PCB
A16B-1300-0220	SENSOR SGNL CONVERSION PCB
A16B-1300-0221	SENSOR SGNL CONVERSION PCB
A16B-1310-0010	POWER SUPPLY PCB
A16B-1310-0111	A03B-0801-C117 MODULE
A16B-1310-0143	A03B-0801-C127 MODULE
A16B-1310-0161	A03B-0801-C133 MODULE
A16B-1310-0300	6 CNTRL ACP MEMORY A PCB
A16B-1310-0310	10 CNTRL PCB
A16B-1310-0380	0 CONTROL PCB
A16B-1310-0530	ROBOT PCB
A16B-1310-0600	ROBOT PCB
A16B-1310-0660	LASER POWER SUPPLY PCB
A16B-1400-0151	FANUC PCB
A16B-1500-0010	INPUT UNIT PCB
A16B-1500-0021	INPUT UNIT PCB
A16B-1600-0042	3T KEYBOARD
A16B-1600-0043	KEYBOARD PCB
A16B-1600-0070	KEYBOARD PCB
A16B-1600-0080	INPUT UNIT PCB
A16B-1600-0090	INPUT UNIT PCB
A16B-1600-0150	ROBOT INPUT UNIT PCB
A16B-1600-0210	FANUC PCB
A16B-1600-0280	ADDITIONAL ROM PCB
A16B-1600-0281	15A ADD. ROM PCB
A16B-1600-0320	FANUC PCB
A16B-1600-0440	FANUC PCB
A16B-1600-0661	CONNECTION PCB
A16B-1600-0740	INTERFACE PCB

A16B-1600-0800	INPUT UNIT PCB
A16B-1700-0020	ANALOG SPINDLE PCB
A16B-1700-0130	SIGNAL CONVERSION PCB
A16B-1700-0160	LASER RELAY PCB
A16B-1810-0010	0 CNTRL 3-AXIS PCB
A16B-1810-0040	F/C1-C4 ADD DETECTOR PCB
A16B-1810-0041	F/A4-A6 ADD DETECTOR PCB
A16B-2000-0141	BASE 2 W/SUB CPU PCB
A16B-2000-0360	FANUC PCB
A16B-2000-0520	FANUC PCB
A16B-2001-0890	MAIN PCB FOR 6081-H103/H106
A16B-2100-0030	6064 SPINDLE DRIVE PCB
A16B-2100-0070	6064 SPINDLE PCB
A16B-2100-0080	I/O PCB
A16B-2100-0110	FANUC PCB
A16B-2200-0020	15 CNTRL BASE 2 PCB
A16B-2200-0021	15 A 16 BIT 2 AXES PCB
A16B-2200-0080	15 A BASE 2 W/2 AXES PCB
A16B-2200-0090	15TTA CNTRL AXIS 01P61 PCB
A16B-2200-0091	15 A THREE AXES PCB
A16B-2200-0092	15TTA CNTRL AXIS 02P61 PCB
A16B-2200-0093	15 A SINGLE AXES PCB
A16B-2200-0113	15 A PMC RAM PCB
A16B-2200-0120	15 A BASE ZERO PCB
A16B-2200-0121	15 A BASE ZERO PCB
A16B-2200-0124	15 A BASE ZERO PCB
A16B-2200-0127	15 A BASE ZERO PCB
A16B-2200-0129	15 A BASE ZERO PCB
A16B-2200-0130	15 A BASE 1 PMC CPU PCB
A16B-2200-0131	15 TTA CNTRL BASE 1 01D1D PCB
A16B-2200-0140	15 A SUB CPU BASE 2 PCB
A16B-2200-0141	15 A BASE 2 SUB CPU PCB
A16B-2200-0160	15 CNTRL GRAPHIC CPU PCB
A16B-2200-0170	15 CNTRL REMOTER BUFFER PCB
A16B-2200-0171	15 TTA CNTRL SERIAL 01P26 PCB
A16B-2200-0173	SER PORT W/ANALOG SPNDL PCB
A16B-2200-0200	ROBOT PCB
A16B-2200-0210	RG2 ROBOT MEMORY PCB
A16B-2200-0211	RG2 ROBOT MEMORY PCB
A16B-2200-0220	0 CONTROL 16 BIT 3/4 AXES PCB
A16B-2200-0221	0 CNTRL DIGITAL 1-2 AXIS PCB
A16B-2200-0240	CRT/MDI ADAPTER PCB

A16B-2200-0250	RH ROBOT AXES PCB
A16B-2200-0251	RH ROBOT AXES PCB
A16B-2200-0252	RH ROBOT AXES PCB
A16B-2200-0300	FANUC PCB
A16B-2200-0310	GRAPHIC CONTROL PCB
A16B-2200-0320	0 CNTRL SUB-CPU PCB
A16B-2200-0330	0 CONTROL 5/6 AXES PCB
A16B-2200-0340	0 CNTRL PMC M PCB
A16B-2200-0341	0 CNTRL PMC M PCB
A16B-2200-0346	0 CNTRL PMC RAM PCB
A16B-2200-0350	0 CNTRL GRAPHIC CONTROL PCB
A16B-2200-0360	0 CNTRL 1/4 AXIS PCB
A16B-2200-0361	0 CNTRL 2 AXIS PCB
A16B-2200-0371	0 CNTRL 5/6 AXIS PCB
A16B-2200-0380	0 CNTRL 7/8 AXIS PCB
A16B-2200-0381	0 CNTRL 7 AXIS PCB
A16B-2200-0390	0 CNTRL SER: AI-4AX6S PCB
A16B-2200-0391	0 C 2 AXES PCB
A16B-2200-0430	I/O PCB
A16B-2200-0431	ROBOT PCB
A16B-2200-0440	FANUC PCB
A16B-2200-0470	15 A BASE 1 PCB
A16B-2200-0471	15 A BASE 1 PCB
A16B-2200-0490	POWERMATE PCB
A16B-2200-0500	MAIN CPU PCB
A16B-2200-0510	GRAPHIC CONTROL A PCB
A16B-2200-0520	15 A B2 BASE ZERO PCB
A16B-2200-0521	15 TTA CNTRL BASE 0 01P1E PCB
A16B-2200-0524	15 A BASE ZERO PCB
A16B-2200-0630	AXES PCB
A16B-2200-0660	I/O OPERATOR PANEL PCB
A16B-2200-0661	18 CNTRL PCB
A16B-2200-0670	6064 SPINDLE PCB
A16B-2200-0690	15 A SERIAL AXES PCB
A16B-2200-0700	18 CNTRL PCB
A16B-2200-0754	RG2 ROBOT MEMORY PCB
A16B-2200-0755	15 A RBU PCB
A16B-2200-0760	ROBOT 2 MEG RAM FILE PCB
A16B-2200-0761	ROBOT 1 MEG RAM FILE PCB
A16B-2200-0775	REMOTE BUFFER/DNC2 PCB
A16B-2200-0790	SERIAL 7/8 FEEDBACK AXES PCB
A16B-2200-0800	5TH/6TH AXES SERIAL PCB
A16B-2200-0842	RJ ROBOT MAIN PCB

A16B-2200-0843	RJ ROBOT MAIN PCB
A16B-2200-0852	ROBOT PCB
A16B-2200-0854	ROBOT 8 AXES PCB
A16B-2200-0855	ROBOT 6 AXES PCB
A16B-2200-0860	18 TA MAIN CPU PCB
A16B-2200-0900	15 CNTRL PCB
A16B-2200-0901	16 CONTROL MAIN CPU PCB
A16B-2200-0910	16 MA OPTION 1 PCB
A16B-2200-0911	ROBOT PCB
A16B-2200-0913	REMOTE BUFFER PCB
A16B-2200-0915	16 CONTROL GRAPHIC PCB
A16B-2200-0917	16MA CNTRL OPT 1 PCB
A16B-2200-0919	15TTB CNTRL OPT 1 PCB
A16B-2200-0930	16TTA CNTRL I/O PCB
A16B-2200-0931	16MA CNTRL OPT 2 PCB
A16B-2200-0942	16MA CNTRL OPT 3 PCB
A16B-2200-0950	16 CONTROL I/O PCB
A16B-2200-0951	16 CONTROL I/O PCB
A16B-2200-0952	16 CONTROL I/O PCB
A16B-2200-0953	16 CONTROL I/O PCB
A16B-2200-0954	16 CONTROL I/O PCB
A16B-2200-0955	16TTA I/O PCB
A16B-2200-0956	16 CONTROL I/O PCB
A16B-2200-0957	16 CONTROL I/O PCB
A16B-2200-0960	16 CNTRL LADDER LOADER PCB
A16B-2201-0010	6064 SPINDLE DRIVE PCB
A16B-2201-0020	6058-2 AXIS O/S PCB
A16B-2201-0021	6058-2 AXIS N/S PCB
A16B-2201-0070	POWERMATE I/O PCB
A16B-2201-0071	POWERMATE I/O PCB
A16B-2201-0080	15/16 CNTRL PCB
A16B-2201-0091	SUB CPU W/O GRAPHICS PCB
A16B-2201-0100	0 MEMORY W/SIC & SLC PCB
A16B-2201-0101	0 CNTRL MEMORY PCB
A16B-2201-0103	0 MEMORY WO/SK & SLC PCB
A16B-2201-0110	0 MEMORY W/SIC & SLC PCB
A16B-2201-0120	18 CONTROL MAIN CPU PCB
A16B-2201-0121	FANUC PCB
A16B-2201-0131	6 & 11 CONTROL SRAM
A16B-2201-0132	6 CNTRL SRAM (BMU) PCB
A16B-2201-0133	6 & 11 CONTROL SRAM
A16B-2201-0134	6 & 11 CONTROL SRAM
A16B-2201-0135	6 CNTRL SRAM (BMU) PCB
A16B-2201-0136	6 & 11 CONTROL SRAM
A16B-2201-0311	15 TTB ADAX PCB

A16B-2201-0440	6064 SPINDLE PCB
A16B-2201-0450	POWERMATE C PCB
A16B-2201-0470	RJ2 ROBOT I/O PCB
A16B-2201-0472	RJ2 ROBOT I/O PCB
A16B-2201-0630	PCBIN POWER MATE D CNTRL PCB
A16B-2201-0722	21 TA MAIN CPU PCB
A16B-2201-0772	FANUC PCB
A16B-2201-0810	15TFB PMC-NB PCB
A16B-2201-0851	15TTB PMB-NB PCB
A16B-2201-0854	OPT-3 PMC-RC3/RC4 PCB
A16B-2201-0880	POWERMATE E PCB
A16B-2201-0890	ETHERNET REMOTE PCB
A16B-2201-0922	21TA POWER SUPPLY W/ I/O PCB
A16B-2201-0933	VCU CONNECTION PCB
A16B-2202-0011	SERVO PCB
A16B-2202-0070	SPINDLE PCB
A16B-2202-0181	POWERMATE PCB
A16B-2202-0251	21TA CNTRL PCB
A16B-2202-0401	16 CNTRL OPT2 W/O SUB CPU
A16B-2202-0420	6077 POWER SUPPLY PCB
A16B-2202-0421	6087 POWER SUPPLY PCB
A16B-2202-0422	MAIN PCB FOR 6091 POWER SUP.
A16B-2202-0431	MAIN PCB FOR 6078 SPINDLE DR.
A16B-2202-0432	6055 SPINDLE DRIVE PCB
A16B-2202-0434	PCB FOR 6078 SPINDLE DRIVE
A16B-2202-0435	CONTROL PCB FOR 6088 SP. DR.
A16B-2202-0440	6088 DRIVE PCB
A16B-2202-0471	WIRING PCB FOR 6078 SP. DR.
A16B-2202-0472	WIRING PCB FOR 6078 SP. DR.
A16B-2202-0541	WIRING PCB FOR 6081 PWR. SUP.
A16B-2202-0542	WIRING PCB FOR 6081 PWR. SUP.
A16B-2202-0661	6077 DRIVE PCB
A16B-2202-0680	FANUC PCB
A16B-2202-0681	6078/6102 SPINDLE DRIVE PCB
A16B-2202-0682	6078/6102 SPINDLE DRIVE PCB
A16B-2202-0720	16MC CNTRL I/O PCB
A16B-2202-0730	OPP. PANEL I/O PCB
A16B-2202-0731	16 CONTROL PCB
A16B-2202-0740	PWB PCB FOR 6079/6096 H101
A16B-2202-0741	PWB PCB FOR 6079/6096 H102
A16B-2202-0742	PWB PCB FOR 6079/6096 H121

A16B-2202-0743	PWB PCB FOR 6079/6096 H122
A16B-2202-0750	PWB PCB FOR 6079/6096 H201
A16B-2202-0751	PWB PCB FOR 6079/6096 H202
A16B-2202-0752	PWB PCB FOR 6079/6096 H203
A16B-2202-0753	PWB PCB FOR 6079/6096 DRIVE
A16B-2202-0770	PWB PCB FOR 6079/6096 DRIVE
A16B-2202-0774	CONN. PCB FOR 6096-H208
A16B-2202-0780	DRIVE
A16B-2202-0781	PWB PCB 6079,6080,6096-H301
A16B-2202-0782	PWB PCB 6079,6080,6096-H302
A16B-2202-0783	PWB PCB 6079,6080,6096-H303
A16B-2202-0784	PWB PCB 6079,6080,6096-H304
A16B-2202-0785	PWB PCB 6079,6080,6096-H305
A16B-2202-0786	PWB PCB 6079,6080,6096-H306
A16B-2202-0790	PWB PCB 6079,6080,6096-H307
A16B-2202-0831	PCB FOR 6079-H106 SERVO
A16B-2202-0832	DRIVE
A16B-2202-0840	POWER MATE E PCB
A16B-2202-0850	POWER MATE E PCB
A16B-2202-0853	6082 SPINDLE DRIVE PCB
A16B-2202-0860	21 CONTROL OPTION 2 PCB
A16B-2202-0900	21 CNTRL OPT 2 TWO AXES PCB
A16B-2202-0980	18TTB FS18B MAIN PCB
A16B-2202-0990	21 CONTROL MAIN CPU PCB
A16B-2202-0991	I/O 9" CRT PCB
A16B-2203-0020	MAIN PCB FOR 6079/6096 H107
A16B-2203-0021	MAIN PCB FOR 6079/6096 H108
A16B-2203-0041	0 CNTRL 4 AXES INTERFACE
A16B-2203-0110	PCB
A16B-2203-0220	O CONTROL 2 AXES PCB
A16B-2203-0240	21 CONTROL 48/32 I/O PCB
A16B-2203-0300	O CONTROL 104/72 I/O PCB
A16B-2203-0301	MAIN PCB FOR 6098-H111
A16B-2203-0331	PWR.SP
A16B-2203-0332	ROBOT MEMORY PCB
A16B-2203-0450	MAIN PCB FOR 6096-H107 DRIVE
A16B-2203-0451	MAIN PCB FOR 6096-H108 DRIVE
A16B-2203-0452	MAIN PCB FOR 6078-H211 SP.
	DR.
	PCB FOR 6088-H222 SPINDLE
	DR.
	PWB PCB FOR 6079/6096-H103
	DR
	PWB PCB FOR 6079/6096-H104
	DR
	PWB PCB FOR 6079/6096-H105

A16B-2203-0453	DR PWB PCB FOR 6079/6096-H116
A16B-2203-0454	DR PWB PCB FOR 6079/6096-H106
A16B-2203-0502	DR MAIN PCB FOR 6102 SPINDLE
A16B-2203-0590	DR. PWB PCB FOR 6079/6096-H204
A16B-2203-0591	DR PWB PCB FOR 6079/6096-H205
A16B-2203-0592	DR PWB PCB FOR 6079/6096-H206
A16B-2203-0593	DR PWB PCB FOR 6079/6096-H207
A16B-2203-0594	DR PWB PCB FOR 6079/6096-H208
A16B-2203-0595	DR PWB PCB FOR 6079/6096-H209
A16B-2220-0740	DR PWB PCB FOR 6079/6096-H101
A16B-2300-0020	48/32 SUB I/O PCB
A16B-2300-0022	32/24 SUB I/O PCB
A16B-2300-0080	LCD/MDI POWER SUPPLY PCB
A16B-2300-0110	O OPERATOR PANEL I/O PCB
A16B-2300-0140	LCD/MDI PCB
A16B-2400-0010	6065 HV SPINDLE DRIVE PCB
A16B-3200-0010	16 B MAIN CPU PCB
A16B-3200-0020	21 B MAIN CPU PCB
A16B-3200-0040	ROBOT MAIN CPU PCB
A16B-3200-0054	16 B OPTION 3 PCB
A16B-3200-0060	15TTB MAIN-C PCB
A16B-3200-0070	RJ2 ROBOT MAIN CPU PCB
A16B-3200-0150	21 CNTRL HIGH SPD. BUFFER PCB
A16B-3200-0160	18 B MAIN PCB
A16B-3200-0170	16 A MAIN PCB
A16B-3200-0190	15TTB FS16/18 MAIN PCB
A16B-3200-0210	18 MAIN CPU PCB
A16B-3200-0230	RJ2 I/O PCB
A16B-3300-0037	LCD GRAPHIC PCB
A16B-3300-0057	LCD GRAPHIC PCB

A20B-0001-0650	POWER SUPPLY PCB
A20B-0001-0831	KEYBOARD FOR 200 B CNTRL
A20B-0002-0550	FANUC PCB
A20B-0002-0920	FANUC PCB
A20B-0002-0940	2000/3000 CONTROL PCB
A20B-0002-0942	2000 CONTROL # 2 SLOT PCB
A20B-0002-0943	2000/3000 CONTROL PCB
A20B-0003-0210	2000/3000 CNTRL DISPLAY PCB
A20B-0003-0310	POWER SUPPLY PCB
A20B-0003-0310	2000/3000 POWER SUPPLY
A20B-0003-0490	DC SPINDLE PWR SUPPLY PCB
A20B-0003-0630	POWER SUPPLY PCB
A20B-0003-0740	5 CONTROL PCB
A20B-0003-0741	5 CNTRL PCB A PCB
A20B-0003-0742	5 CNTRL PCB A PCB
A20B-0003-0744	5 CNTRL 2 AXIS A PCB
A20B-0003-0745	5 CNTRL 3 AXIS A PCB
A20B-0003-0751	5 CNTRL PCB B PCB
A20B-0003-0752	5 CONTROL PCB
A20B-0003-0754	5 CNTRL 2 AXIS B PCB
A20B-0003-0755	5 CNTRL 3 AXIS B PCB
A20B-0003-0760	2000/3000 CNTRL DISPLAY PCB
A20B-0003-0761	2000/3000 CNTRL DISPLAY PCB
A20B-0003-0770	5 CNTRL PCB
A20B-0003-0772	SEQUENCE CONTROL PCB
A20B-0003-0773	5 CONTROL PCB
A20B-0003-0776	5 CONTROL PCB
A20B-0003-0830	5 CNTRL PCB
A20B-0003-0880	TAPE READER PCB
A20B-0003-0900	5 POWER SUPPLY PCB
A20B-0003-0900	POWER SUPPLY PCB
A20B-0003-0902	POWER SUPPLY PCB
A20B-0004-0010	5 CONTROL MDI/DPL PCB
A20B-0004-0011	5 CONRTOL MDI/DPL PCB
A20B-0004-0042	OPTICAL UNIT PCB
A20B-0004-0050	CONNECTION UNIT PCB
A20B-0004-0060	CONNECTION UNIT PCB
A20B-0004-0170	STEP 3 DRIVE PCB W/ POWER SUPPLY
A20B-0004-0171	STEP 3 DRIVE PCB W/O POWER SUPPLY
A20B-0004-0270	TAPE READER PCB
A20B-0004-0280	TAPE READER PCB
A20B-0004-0500	5 CNTRL MEMORY PCB
A20B-0004-0510	5 CNTRL KEYBOARD PCB
A20B-0004-0720	POWER SUPPLY PCB

A20B-0004-0880	5 CNTRL PCB
A20B-0004-0942	7 CONTROL PCB
A20B-0004-0971	7 CONTROL PCB
A20B-0004-0990	6041 DC SPINDLE DRIVE PCB
A20B-0004-C006	OPTION UNIT
A20B-0005-0080	PRE AMP PCB
A20B-0005-0130	FANUC PCB
A20B-0005-0290	5 CNTRL POSITION DISPLAY PCB
A20B-0005-0320	5 CNTRL DISPLAY PCB
A20B-0005-0321	5 CNTRL MDI/DTL UNIT PCB
A20B-0005-0322	5 CONTROL MDI/DPL PCB
A20B-0005-0370	DC SPINDLE DRIVE PCB
A20B-0005-0371	DC SPINDLE DRIVE PCB
A20B-0005-0372	DC SPINDLE DRIVE PCB
A20B-0005-0373	DC SPINDLE DRIVE PCB
A20B-0005-0374	DC SPINDLE DRIVE PCB
A20B-0005-0375	DC SPINDLE DRIVE PCB
A20B-0005-0376	DC SPINDLE DRIVE PCB
A20B-0005-0377	DC SPINDLE DRIVE PCB
A20B-0005-0378	DC SPINDLE DRIVE PCB
A20B-0005-0379	DC SPINDLE DRIVE PCB
A20B-0005-0450	5 POWER SUPPLY PCB
A20B-0005-0450	POWER SUPPLY PCB
A20B-0005-0530	POWER SUPPLY PCB
A20B-0005-0540	POWER SUPPLY PCB
A20B-0005-0583	DC SPINDLE DRIVE PCB
A20B-0005-0584	DC SPINDLE DRIVE PCB
A20B-0005-0610	DC SPINDLE DRIVE PCB
A20B-0005-0611	DC SPINDLE DRIVE PCB
A20B-0005-0612	DC SPINDLE DRIVE PCB
A20B-0005-0690	7 CNTRL PCB
A20B-0005-0700	7 CNTRL PCB
A20B-0005-0711	7 CNTRL PCB
A20B-0005-0730	7 CONTROL KEYBOARD PCB
A20B-0005-0733	POWER SUPPLY PCB
A20B-0005-0740	7 CNTRL PCB
A20B-0005-0754	5 CONTROL MDI/DPL PCB
A20B-0005-0767	OPERATOR PANEL PCB
A20B-0005-0780	2000/3000 CNTRL PCB
A20B-0005-0940	6042 POWER SUPPLY PCB
A20B-0005-0941	6042 POWER SUPPLY PCB
A20B-0005-0942	6042 POWER SUPPLY PCB
A20B-0005-0943	6042 POWER SUPPLY PCB
A20B-0006-0030	FANUC PCB
A20B-0006-0060	7 POWER SUPPLY PCB

A20B-0006-0060	7 CONTROL POWER SUPPLY PCB
A20B-0006-0232	7 CNTRL PCB
A20B-0006-0500	L SERIES DC SERVO DRIVE PCB
A20B-0006-0640	5 CNTROL PCB
A20B-0006-0870	SYSTEM P MDL D PROGRAMMER PCB
A20B-0006-0880	STSTEM P MDL D PROGRAMMER PCB
A20B-0007-0010	6A CNTRL MASTER PCB
A20B-0007-0020	2000/3000 CNTRL DISPLAY PCB
A20B-0007-0030	6 CNTRL CRT/MDI PCB
A20B-0007-0040	6 CNTRL I/O PCB
A20B-0007-0041	I/O INTERFACE PCB
A20B-0007-0045	HARDINGE I/O PCB
A20B-0007-0060	6 A CONTROL PUNCHER PCB
A20B-0007-0061	6 CNTRL PCB
A20B-0007-0070	6 CNTRL CRTC PCB
A20B-0007-0090	6 CNTRL ADD AXIS PCB
A20B-0007-0270	7 CNTRL PCB
A20B-0007-0271	7 CNTRL PCB
A20B-0007-0330	A14B-0061-B001 POWER SUPPLY PCB
A20B-0007-0340	INPUT UNIT POWER SUPPLY
A20B-0007-0340	POWER SUPPLY FOR INPUT UNIT
A20B-0007-0360	STEP 4 DRIVE PCB W/ POWER SUPPLY
A20B-0007-0361	STEP 4 DRIVE PCB W/O POWER SUPPLY
A20B-0007-0430	6 A CONTROL MDI/DPL UNIT PCB
A20B-0007-0440	6 A CONTROL KEYBOARD PCB
A20B-0007-0441	6 CNTRL KEYBOARD PCB
A20B-0007-0444	FANUC PCB
A20B-0007-0445	5 CONTROL MDI/DPL PCB
A20B-0007-0449	CRT/MDI PCB
A20B-0007-0500	FANUC PCB
A20B-0007-0750	6 CNTRL PCB
A20B-0007-T022	5 CONTROL MDI/DPL UNIT
A20B-0008-0030	ORIENTATION PCB
A20B-0008-0031	SPINDLE ORIENTATION PCB
A20B-0008-0032	ORIENTATION PCB
A20B-0008-0033	SPINDLE ORIENTATION PCB
A20B-0008-0190	FANUC PCB

A20B-0008-0200	3 CONTROL MASTER PCB
A20B-0008-0220	3 M CNTRL CRT/MDI UNIT KEYBOARD
A20B-0008-0230	3 M CONTROL CRT/MDI UNIT PCB
A20B-0008-0240	SPINDLE ORIENTATION PCB
A20B-0008-0241	SPINDLE ORIENTATION PCB
A20B-0008-0242	SPINDLE ORIENTATION PCB
A20B-0008-0243	ORIENTATION PCB
A20B-0008-0244	SPINDLE ORIENTATION PCB
A20B-0008-0245	SPINDLE ORIENTATION PCB
A20B-0008-0271	FANUC PCB
A20B-0008-0280	RS232 INTERFACE PCB
A20B-0008-0370	DC SPINDLE DRIVE PCB
A20B-0008-0371	DC SPINDLE DRIVE PCB
A20B-0008-0372	DC SPINDLE DRIVE PCB
A20B-0008-0373	DC SPINDLE DRIVE PCB
A20B-0008-0374	DC SPINDLE DRIVE PCB
A20B-0008-0375	DC SPINDLE DRIVE PCB
A20B-0008-0376	DC SPINDLE DRIVE PCB
A20B-0008-0377	DC SPINDLE DRIVE PCB
A20B-0008-0378	DC SPINDLE DRIVE PCB
A20B-0008-0379	DC SPINDLE DRIVE PCB
A20B-0008-0410	6B MASTER PCB
A20B-0008-0430	6 CNTRL CRT/PC/PUNCHER PCB
A20B-0008-0440	6 CNTRL PC MODEL B PCB
A20B-0008-0460	6 CONTROL RES/IND PCB
A20B-0008-0461	6 CNTRL RESOLVER/IND PCB
A20B-0008-0470	6 CONTROL ADD AXES (RES) PCB
A20B-0008-0471	6 CNTRL ADD AXIS (INDUCT) PCB
A20B-0008-0480	6 CONTROL ROM PCB
A20B-0008-0500	6 CNTRL M-M INTERFACE PCB
A20B-0008-0540	6 CNTRL I/O PCB
A20B-0008-0630	6 CNTRL PC1 PCB
A20B-0008-0640	FANUCPC 2 PCB
A20B-0008-0670	DC SPINDLE PWR SUPPLY PCB
A20B-0009-0100	SPINDLE CONTROL PCB
A20B-0009-0140	ROBOT RC MASTER PCB
A20B-0009-0150	ROBOT RC PCB
A20B-0009-0170	ROBOT TEACH PENDANT PCB
A20B-0009-0191	POWER SUPPLY PCB
A20B-0009-0320	6047 SINGLE AXIS PCB
A20B-0009-0460	A14B-0070-B002 PWR SUPPLY PCB

A20B-0009-0470	A14B-0070-B002 PWR SUPPLY PCB
A20B-0009-0520	ORIENTATION PCB
A20B-0009-0521	FANUC SPINDLE DRIVE PCB
A20B-0009-0530	0530-0539 AC ANALOG SPINDLE PCB
A20B-0009-0531	0530-0539 AC ANALOG SPINDLE PCB
A20B-0009-0532	0530-0539 AC ANALOG SPINDLE PCB
A20B-0009-0533	0530-0539 AC ANALOG SPINDLE PCB
A20B-0009-0534	0530-0539 AC ANALOG SPINDLE PCB
A20B-0009-0535	0530-0539 AC ANALOG SPINDLE PCB
A20B-0009-0536	0530-0539 AC ANALOG SPINDLE PCB
A20B-0009-0537	0530-0539 AC ANALOG SPINDLE PCB
A20B-0009-0538	0530-0539 AC ANALOG SPINDLE PCB
A20B-0009-0539	0530-0539 AC ANALOG SPINDLE PCB
A20B-0009-0640	A14B-0070-B002 PWR SUPPLY PCB
A20B-0009-0690	FANUC RELAY PCB
A20B-0009-0730	FANUC PCB
A20B-0009-0740	ROBOT TEACH PENDENT PCB
A20B-0009-0930	FANUC ANALOG SPINDLE PCB
A20B-0010-0130	SINGLE AXIS DRIVE PCB
A20B-0041-C019	INPUT UNIT PCB
A20B-0047-C022	2000/3000 DISPLAY PCB
A20B-1000-0010	2000/3000 DISPLAY PCB
A20B-1000-0030	PCB FOR A14B-0061-B002 PWR SUPPLY
A20B-1000-0130	CRT/MDI PCB
A20B-1000-0131	CRT/MDI PCB
A20B-1000-0180	PROGRAMMER POWER SUPPLY
A20B-1000-0180	POWER SUPPLY FOR PROGRAMMER
A20B-1000-0200	PWA I/O CONTROL PCB
A20B-1000-0220	6047 2 AXIS DRIVE PCB
A20B-1000-0390	FANUC KEYBOARD PCB
A20B-1000-0400	POWER SUPPLY PCB

A20B-1000-0410	A14B-0067-B002 PWR SUPPLY PCB
A20B-1000-0470	POWER SUPPLY PCB
A20B-1000-0472	PURGE UNIT POWER SUPPLY
A20B-1000-0472	ROBOT PURGE UNIT PCB
A20B-1000-0480	6 CNTRL 14" COLOR GRAPHIC PCB
A20B-1000-0500	6 CNTRL CRT PCB
A20B-1000-0530	KEYBOARD INTERFACE PCB
A20B-1000-0540	FANUC KEYBOARD PCB
A20B-1000-0550	MC 2 SUB CPU PCB
A20B-1000-0560	6050 SINGLE AXIS DRIVE PCB
A20B-1000-0590	ANALOG SERVO PCB
A20B-1000-0600	AC SV DIG PWR SUPPLY C PCB
A20B-1000-0650	AC SPINDLE SWITCHER PCB
A20B-1000-0660	RELAY UNIT PCB
A20B-1000-0680	FANUC PCB
A20B-1000-0690	AC ANALOG SPINDLE DRIVE PCB
A20B-1000-0691	AC ANALOG SPINDLE DRIVE PCB
A20B-1000-0692	AC ANALOG SPINDLE DRIVE PCB
A20B-1000-0693	AC ANALOG SPINDLE DRIVE PCB
A20B-1000-0694	AC ANALOG SPINDLE DRIVE PCB
A20B-1000-0695	AC ANALOG SPINDLE DRIVE PCB
A20B-1000-0696	AC ANALOG SPINDLE DRIVE PCB
A20B-1000-0697	AC ANALOG SPINDLE DRIVE PCB
A20B-1000-0698	AC ANALOG SPINDLE DRIVE PCB
A20B-1000-0699	AC ANALOG SPINDLE DRIVE PCB
A20B-1000-0700	ANALOG SPINDLE DRIVE PCB
A20B-1000-0701	FANUC DRIVE PCB
A20B-1000-0710	SYSTEM P MDL G PROGRAMMER PCB
A20B-1000-0720	SYSTEM P MDL G PROGRAMMER PCB
A20B-1000-0770	ROBOT POWER SUPPLY
A20B-1000-0770	RF/RH ROBOT POWER SUPPLY
A20B-1000-0800	10-11 CNTRL CRT/MDI PCB

A20B-1000-0802	9" MONO GRAPHIC CONTROL PCB
A20B-1000-0830	FANUC KEYBOARD PCB
A20B-1000-0831	CRT/MDI PCB
A20B-1000-0832	FANUC KEYBOARD PCB
A20B-1000-0840	CRT/MDI PCB
A20B-1000-0841	SOFT KEY KEYBOARD PCB
A20B-1000-0842	KEYBOARD PCB
A20B-1000-0844	SOFT KEY KEYBOARD PCB
A20B-1000-0850	10-11 CNTRL CRT/MDI PCB
A20B-1000-0852	10-11 CNTRL CRT/MDI PCB
A20B-1000-0870	FANUC KEYBOARD PCB
A20B-1000-0880	11 MF CNTRL HORZ. KEYBOARD PCB
A20B-1000-0890	CRT/MDI PCB
A20B-1000-0891	SOFT KEY KEYBOARD PCB
A20B-1000-0900	10-11 CNTRL CRT/MDI PCB
A20B-1000-0910	PMC CASSETTE A PCB
A20B-1000-0913	18 CNTRL PCB
A20B-1000-0920	PMC CASSETTE B PCB
A20B-1000-0940	11 CNTRL I/O PCB
A20B-1000-0950	10/11 CONTROL I/O PCB
A20B-1000-0970	CRT/MDI PCB
A20B-1000-0990	10-11 CNTRL CRT CONTROLLER PCB
A20B-1000-T382	SOFT KEY KEYBOARD PCB
A20B-1001-0030	PCB FOR A03B-0801-C013 MODULE
A20B-1001-0050	TAPE READER PCB
A20B-1001-0060	FANUC KEYBOARD PCB
A20B-1001-0120	AC DIGITAL SPINDLE DRIVE PCB
A20B-1001-0160	CRT/MDI POWER SUPPLY
A20B-1001-0160	CRT/MDI POWER SUPPLY PCB
A20B-1001-0200	6050 2 AXIS DRIVE PCB
A20B-1001-0242	10 CNTRL D3 I/O PCB
A20B-1001-0270	10/11 CNTRL FAPT KEYBOARD PCB
A20B-1001-0410	POWER SUPPLY PCB
A20B-1001-0410	INPUT UNIT POWER SUPPLY
A20B-1001-0470	RF ROBOT MASTER PCB
A20B-1001-0560	CRT/MDI PCB
A20B-1001-0570	CRT/MDI PCB
A20B-1001-0591	CRT/MDI PCB
A20B-1001-0620	6054 SPINDLE DRIVE PCB
A20B-1001-0621	6054 SPINDLE DRIVE PCB

A20B-1001-0710	10/11 CNTRL CRT/MDI PCB
A20B-1001-0711	ROBOT PCB
A20B-1001-0720	CRT/MDI PCB
A20B-1001-0721	CRT/MDI PCB
A20B-1001-0730	FANUC B 1 I/O PCB
A20B-1001-0731	15 CNTRL I/O PCB
A20B-1001-0770	6050 3 AXIS DRIVE PCB
A20B-1001-0820	CRT/MDI SWITCHER PCB
A20B-1001-0830	10-11 CNTRL LVL UP MAIN CPU PCB
A20B-1001-0840	CRT/MDI PCB
A20B-1001-0870	CRT/MDI PCB
A20B-1001-0882	CRT/MDI PCB
A20B-1001-0910	10/11 CNTRL CRT/MDI PCB
A20B-1001-0920	10/11 CNTRL CRT/MDI PCB
A20B-1001-0930	CRT/MDI POWER SUPPLY
A20B-1001-0930	10/11 CNTRL CRT/MDI PCB
A20B-1002-0280	6057 3 AXES SERVO DRIVE PCB
A20B-1002-0290	DETECTOR ADAPTER PCB
A20B-1002-0310	FANUCF 1 I/O PCB
A20B-1002-0330	SOFTWARE PCB
A20B-1002-0350	SOFT KEY KEYBOARD PCB
A20B-1002-0360	DC MASTER PCB
A20B-1002-0450	PCB FOR A03B-0801-C012 BACKPLANE
A20B-1002-0680	GE FANUC POWER UNIT
A20B-1002-0680	POWER SUPPLY MODULE PCB
A20B-1002-0700	0 CNTRL CRT/MDI PCB
A20B-1002-0730	6058 H002 DRIVE PCB
A20B-1002-0740	6058 H002 DRIVE PCB
A20B-1002-0800	FANUC SWITCHER UNIT PCB
A20B-1002-0860	ROBOT BACKPLANE PCB
A20B-1002-0902	10/11 CNTRL LEVEL UP GRAPHIC PCB
A20B-1002-0970	ROBOT TEACH PENDANT PCB
A20B-1003-0010	6059 SPINDLE DRIVE PCB
A20B-1003-0020	6059 PWB DRIVE PCB
A20B-1003-0030	6059 SPINDLE DRIVE PCB
A20B-1003-0040	FANUC RS232 PCB
A20B-1003-0041	ROBOT PCB
A20B-1003-0080	6058 PWB SINGLE AXIS DRIVE PCB
A20B-1003-0081	6058 PWB DRIVE PCB
A20B-1003-0082	6058 PWB DRIVE PCB
A20B-1003-0083	PWB FOR 6058-H012 SERVO AMP

A20B-1003-0084	PWB FOR 6058-H025 SERVO AMP
A20B-1003-0085	PWB FOR 6058-H013 SERVO AMP
A20B-1003-0090	6058 PWB SINGLE AXIS DRIVE PCB
A20B-1003-0120	6059 PWB DRIVE PCB
A20B-1003-0140	6058 PWB DRIVE PCB
A20B-1003-0200	CONNECTION UNIT 2 I/O PCB
A20B-1003-0230	15A MASTER PCB
A20B-1003-0240	15 CNTRL PCB
A20B-1003-0271	PWB FOR 6058-H221 SERVO AMP
A20B-1003-0272	PWB FOR 6058-H222 SERVO AMP
A20B-1003-0273	PWB FOR 6058-H223 SERVO AMP
A20B-1003-0274	PWB FOR 6058-H224 SERVO AMP
A20B-1003-0275	PWB FOR 6058-H225 SERVO AMP
A20B-1003-0276	6058 PWB 2 AXIS DRIVE PCB
A20B-1003-0300	FANUC 6060 SPINDLE DRIVE PCB
A20B-1003-0340	ROBOT CRT PCB
A20B-1003-0350	CONNECTOR PCB
A20B-1003-0370	CONNECTOR PCB
A20B-1003-0381	FANUC RELAY MODULE PCB
A20B-1003-0500	15TTF CNTRL GRAPHIC CPU PCB
A20B-1003-0550	FANUC 6062 SPINDLE DRIVE PCB
A20B-1003-0590	FANUC PCB
A20B-1003-0630	OPP PANEL CONN UNIT PWR SP PCB
A20B-1003-0690	ROBOT BACKPLANE PCB
A20B-1003-0750	ZERO C 16 BIT MASTER PCB
A20B-1003-0760	0 CNTRL MASTER PCB
A20B-1003-0830	PWB FOR 6058-H229 SERVO AMP
A20B-1003-0861	6058 PWB 3 AXIS DRIVE PCB
A20B-1003-0862	PWB FOR 6058-H332 SERVO AMP
A20B-1003-0863	6058 PWB 3 AXIS DRIVE PCB
A20B-1003-0864	6058 PWB 3 AXIS DRIVE PCB
A20B-1003-0891	CRT/MDI SWITCHER PCB

A20B-1003-0920	6063 SPINDLE DRIVE PCB
A20B-1003-0930	FANUC PCB
A20B-1003-0940	FANUC PCB
A20B-1003-0960	PWB FOR 6058-H230 SERVO AMP
A20B-1004-0085	FANUC PCB
A20B-1004-0230	HV SPINDLE DRIVE PCB
A20B-1004-0270	15 A BACKPLANE PCB
A20B-1004-0280	TAPE READER PCB
A20B-1004-0540	6059 SPINDLE DRIVE PCB
A20B-1004-0600	6064 SPINDLE DRIVE PCB
A20B-1004-0640	LCD/MDI UNIT PCB
A20B-1004-0650	RS232 TP RDR PW SUPPLY PCB
A20B-1004-0662	LCD/MDI UNIT PWR SUPPLY PCB
A20B-1004-0671	PWB FOR 6058-H250 SERVO AMP
A20B-1004-0672	PWB FOR 6058-H250 SERVO AMP
A20B-1004-0673	PWB FOR 6058-H250 SERVO AMP
A20B-1004-0730	6064 SPINDLE DRIVE PCB
A20B-1004-0740	6059 SPINDLE DRIVE PCB
A20B-1004-0741	6064 SPINDLE DRIVE PCB
A20B-1004-0742	6064 SPINDLE DRIVE PCB
A20B-1004-0750	SOFT KEY KEYBOARD PCB
A20B-1004-0760	SOFT KEY KEYBOARD PCB
A20B-1004-0770	SOFT KEY KEYBOARD PCB
A20B-1004-0850	6066-H006 SERVO AMP PCB
A20B-1004-0851	6066-H004 SERVO AMP PCB
A20B-1004-0852	6066 SERVO AMP PCB
A20B-1004-0854	PWB FOR 6058-H224 SERVO AMP
A20B-1004-0860	6066-H244 SERVO AMP PCB
A20B-1004-0863	6066-H223 SERVO AMP PCB
A20B-1004-0881	6058 PWB 2 AXIS DRIVE PCB
A20B-1004-0882	PWB FOR 6058-H222 SERVO AMP
A20B-1004-0883	PWB FOR 6058-H223 SERVO AMP
A20B-1004-0885	PWB FOR 6058-H225 SERVO AMP
A20B-1004-0888	PWB FOR 6058-H228 SERVO AMP
A20B-1004-0960	0 POWER SUPPLY FOR POWERMATE

A20B-1005-0050	6066 SERVO AMP PCB
A20B-1005-0090	LASER POWER SUPPLY PCB
A20B-1005-0110	PDP/MDI SWITCHER PCB
A20B-1005-0120	POWER SUPPLY PCB
A20B-1005-0190	6064 SPINDLE DRIVE PCB
A20B-1005-0191	6064 SPINDLE DRIVE PCB
A20B-1005-0310	15 B 96/64 I/O PCB
A20B-1005-0421	POWER SUPPLY PCB
A20B-1005-0590	SOFT KEY KEYBOARD PCB
A20B-1005-0592	PCB FOR 6071-H126 AMP
A20B-1005-0690	PCB FOR 6066-H211 SERVO AMP
A20B-1006-0050	LASER POWER SUPPLY PCB
A20B-1006-0060	LASER POWER SUPPLY PCB
A20B-1006-0114	RJ2 ROBOT POWER CIRCUIT PCB
A20B-1006-0270	KEYBOARD PCB
A20B-1006-0290	ROBOT OPERATORPANEL PCB
A20B-1006-0291	ROBOT OPERATORPANEL PCB
A20B-1006-0300	EMERGENCY STOP PCB
A20B-1006-0440	LASER POWER SUPPLY PCB
A20B-1006-0470	PCB FOR 6087-H115 POWER SUPPLY
A20B-1006-0471	6087 POWER SUPPLY PCB
A20B-1006-0472	PCB FOR 6087-H130 POWER SUPPLY
A20B-1006-0480	PWB FOR 6088-H215 SPINDLE DRIVE
A20B-1006-0481	PWB FOR 6088-H222 SPINDLE DRIVE
A20B-1006-0482	PWB FOR 6088-H226 SPINDLE DRIVE
A20B-1006-0483	PWB FOR 6088-H230 SPINDLE DRIVE
A20B-1006-0485	PWB FOR 6079/6096 H107/H108 DRIVE
A20B-1006-0560	FANUC CONNECTOR PCB
A20B-1006-0610	PWB FOR 6091-H130POWER SUPPLY
A20B-1006-0611	PWB FOR 6091-H118 POWER SUPPLY
A20B-1006-0612	PWB FOR 6091-H145 POWER SUPPLY
A20B-1006-0670	SOFT KEY KEYBOARD PCB
A20B-1006-0680	PWB FOR 6087-H145 POWER SUPPLY

A20B-1006-0681	PWB FOR 6091-H175 POWER SUPPLY
A20B-1006-0970	SOFT KEY KEYBOARD PCB
A20B-1007-0200	PWB FOR 6098-H111 POWER SUPPLY
A20B-1007-0440	FANUC PCB
A20B-1007-0650	PWB FOR 6087-H155 POWER SUPPLY
A20B-1200-0800	6058 PWB 2 AXIS DRIVE PCB
A20B-2000-0040	15 CNTRL PCB
A20B-2000-0140	FANUC PCB
A20B-2000-0150	PCB FOR A02B-0098-C199
A20B-2000-0170	0C CNTRL MASTER PCB
A20B-2000-0175	ZERO C CONTROL MASTER PCB
A20B-2000-0180	0C CNTRL MASTER PCB
A20B-2000-0200	ADAPTER POWER SUPPLY
A20B-2000-0200	TAPE READER PCB
A20B-2000-0220	SPINDLE DRIVE PCB
A20B-2000-0330	TAPE READER PCB
A20B-2000-0360	ZERO C CONTROL AXES PCB
A20B-2000-0410	FANUC I/O LINK PCB
A20B-2000-0411	CRT/MDI PCB
A20B-2000-0412	FANUC I/O LINK PCB
A20B-2000-0480	0C CNTRL MASTER PCB
A20B-2000-0520	FANUC PCB
A20B-2000-0620	3 SLOT BACKPLANE PCB
A20B-2000-0630	2 SLOT BACKPLANE PCB
A20B-2000-0640	16MC PCB
A20B-2000-0650	FANUC PCB
A20B-2000-0670	POWERMATE D PCB
A20B-2000-0710	15B PCB
A20B-2000-0720	6 SLOT BACKPLANE PCB
A20B-2000-0840	CRT/MDI PCB
A20B-2000-0880	FANUC BACKPLANE PCB
A20B-2001-0011	COMMON CONVERTER PCB
A20B-2001-0060	0 CNTRL MASTER PCB
A20B-2001-0065	0 CNTRL MASTER PCB
A20B-2001-0120	ZERO D CONTROL MASTER PCB
A20B-2001-0190	4 SLOT BACKPLANE PCB
A20B-2001-0510	LCD/MDI CONNECTOR PCB
A20B-2001-0600	FANUC SENSOR PCB
A20B-2001-0700	6088 DRIVE PCB
A20B-2001-0781	CONN PCB FOR 6082-H211 SP AMP

A20B-2001-0840	CONTROL PCB FOR 7.2" LCD
A20B-2001-0920	FANUC MASTER PCB
A20B-2001-0930	PCB FOR 6079 SERVO AMP
A20B-2001-0931	PCB FOR 6079 SERVO AMP
A20B-2001-0932	PCB FOR 6079 SERVO AMP
A20B-2001-0933	PCB FOR 6079 SERVO AMP
A20B-2001-0940	PCB FOR 6079 SERVO AMP
A20B-2001-0950	PCB FOR 6080 SERVO AMP
A20B-2002-0020	3 SLOT BACKPLANE PCB
A20B-2002-0031	INTERFACE PCB FOR 6089/6090 AMP
A20B-2002-0032	6089 DRIVE PCB
A20B-2002-0040	PCB FOR 6089-H104 SERVO AMP
A20B-2002-0041	PCB FOR 6089-H105 SERVO AMP
A20B-2002-0045	PCB FOR 6089 SERVO AMP
A20B-2002-0050	6089 DRIVE PCB
A20B-2002-0067	6089 DRIVE PCB
A20B-2002-0070	10/11 MMC CPU PCB
A20B-2002-0080	6087 DRIVE CARD PCB
A20B-2002-0090	18B PCB
A20B-2002-0140	15 CNTRL BASE 2 PCB
A20B-2002-0157	6090 DRIVE PCB
A20B-2002-0210	PLUG IN PCB W/FIBER OPTIC
A20B-2002-0300	FANUC SENSOR PCB
A20B-2002-0310	FANUC SENSOR PCB
A20B-2002-0450	ZERO MATE CNTRL MASTER PCB
A20B-2002-0460	FANUC MASTER PCB
A20B-2002-0470	CONNECTION UNIT PCB
A20B-2002-0520	FANUC I/O MODULE PCB
A20B-2002-0521	FANUC I/O MODULE PCB
A20B-2002-0530	6098 DRIVE CARD PCB
A20B-2002-0620	FANUC I/O MODULE PCB
A20B-2002-0650	ZERO C CONTROL MASTER PCB
A20B-2002-0651	ZERO D CONTROL MASTER PCB
A20B-2002-0660	ZERO CONTROL MASTER PCB
A20B-2100-0090	RJ2TEACH PENDANT PCB
A20B-2100-0160	POWERMATEPCB
A20B-2100-0251	6096 DRIVE CARD PCB
A20B-2100-0260	6096 DRIVE MAIN PCB
A20B-2100-0540	9096 DRIVE MAIN PCB
A20B-2100-0541	6096 DRIVE MAIN PCB

A20B-2100-0542	6096 DRIVE INTERFACE PCB
A20B-2100-0543	6096 DRIVE MAIN PCB
A20B-2202-0900	21 BCONTROL MAIN CPU PCB
A20B-2900-0030	DMAMODULE
A20B-2900-0060	SCC MODULE
A20B-2900-0102	16 CNTRL PCB
A20B-2900-0103	MAIN CPU MODULE W/ANALOG SPNDL
A20B-2900-0106	16A CNTRL PCB
A20B-2900-0108	16 CNTRL PCB
A20B-2900-0110	16 CNTRL PCB
A20B-2900-0140	16 CNTRL PCB
A20B-2900-0142	POWERMATE PCB
A20B-2900-0143	16 CNTRL PCB
A20B-2900-0150	14" CRT MODULE
A20B-2900-0151	21A PCB
A20B-2900-0154	14" CRT MODULE
A20B-2900-0155	16 CNTRL PCB
A20B-2900-0156	10" LCD MODULE
A20B-2900-0160	POWERMATE PCB
A20B-2900-0290	16 CNTRL PCB
A20B-2900-0291	15B CNTRL PCB
A20B-2900-0292	512KB ROM PCB
A20B-2900-0293	16A CNTRL PCB
A20B-2900-0310	16 CNTRL PCB
A20B-2900-0311	15B CNTRL PCB
A20B-2900-0340	16 CNTRL PCB
A20B-2900-0350	15B CNTRL PCB
A20B-2900-0361	MFI (DMA) COMM MODULE
A20B-2900-0370	16 CNTRL PCB
A20B-2900-0371	COMMUNICATIONS MODULE
A20B-2900-0380	16A CNTRL PCB
A20B-2900-0390	16 CNTRL PCB
A20B-2900-0430	FANUC MODULE
A20B-2900-0440	FANUC MODULE
A20B-2900-0442	FANUC MODULE
A20B-2900-0450	FANUC MODULE
A20B-2900-0480	ROM MODULE
A20B-2900-0482	FANUC MODULE
A20B-2900-0490	FANUC MODULE
A20B-2900-0491	FANUC MODULE
A20B-2900-0492	FANUC MODULE
A20B-2900-0500	FANUC MODULE
A20B-2900-0501	FANUC MODULE
A20B-2900-0530	POWERMATE PCB
A20B-2900-0531	16 CNTRL PCB

A20B-2900-0541	15B CNTRL PCB
A20B-2900-0552	16 CNTRL PCB
A20B-2900-0555	18 CNTRL PCB
A20B-2900-0560	PMC MODULE
A20B-2900-0581	FANUCMODULE
A20B-2900-0590	GRAPHIC CPU MODULE
A20B-2900-0610	6066 DRIVE PCB
A20B-2900-0620	6066 DRIVE PCB
A20B-2900-0630	6066 DRIVE PCB
A20B-2900-0672	18 CNTRL PCB
A20B-2900-0690	14" CRT MODULE
A20B-2900-0691	15B CNTRL PCB
A20B-2900-0700	15B CNTRL PCB
A20B-2900-0811	4 MB ROM MODULE
A20B-2900-0841	POWERMATE C MEMORY MODULE
A20B-2900-0850	21A CNTRL PCB
A20B-2900-0860	POWERMATE C COMM. MODULR
A20B-2900-0870	POWERMATE C SERVO MODULE
A20B-2900-0900	CPU MODULE
A20B-2900-0901	
A20B-2900-0930	SUB CPU MODULE
A20B-2901-0122	2 MB ROM MODULE
A20B-2901-0200	SUB CPU MODULE
A20B-2901-0240	FANUC MODULE
A20B-2901-0340	16A CNTRL PCB
A20B-2901-0360	15B CNTRL PCB
A20B-2901-0380	SIF MODULE
A20B-2901-0390	15B CNTRL PCB
A20B-2901-0480	PCB FOR POWERMATE
A20B-2901-0500	PCB FOR POWERMATE
A20B-2901-0581	15B CNTRL PCB
A20B-2901-0660	21A CNTRL PCB
A20B-2901-0700	SERVO INTERFACE MODULE
A20B-2901-0716	128K SRAM 3.5MB DRAM MODULE
A20B-2901-0761	MEMORY MODULE W/SERIAL SPINDLE
A20B-2901-0763	SP CNTRL MODULE W/ADD MEMORY
A20B-2901-0765	MEMORY MODULE W/SERIAL SPINDLE
A20B-2901-0851	6088 DRIVE PCB
A20B-2901-0941	15B CNTRL PCB

A20B-2901-0942	18B CNTRL PCB
A20B-2901-0960	18B CNTRL PCB
A20B-2901-0980	SPIF MODULE
A20B-2901-0981	18B CNTRL PCB
A20B-2901-0982	ANALOG SPINDLE MODULE
A20B-2901-0986	ANALOG SPINDLE MODULE
A20B-2902-0060	SERVO CONTROL MODULE
A20B-2902-0070	
A20B-2902-0070	18B CNTRL PCB
A20B-2902-0094	FLASH ROM MODULE
A20B-2902-0190	FANUC MODULE
A20B-2902-0193	15B CNTRL PCB
A20B-2902-0198	512 KB DRAM MODULE
A20B-2902-0224	SER SPNDL W/256K RAM MODULE
A20B-2902-0236	POWERMATE PCB
A20B-2902-0241	DAUGHTER PCB
A20B-2902-0270	
A20B-2902-0271	18B CNTRL PCB
A20B-2902-0272	9.5" + 8.4" LCD MODULE
A20B-2902-0277	CRTC MODULE
A20B-2902-0278	DAUGHTER PCB
A20B-2902-0280	6066/6090 DRIVE CARD PCB
A20B-2902-0290	SERVO CONTROL MODULE
A20B-2902-0341	MEMORY MODULE
A20B-2902-0343	18B CNTRL PCB
A20B-2902-0350	18B CNTRL PCB
A20B-2902-0351	18B CNTRL PCB
A20B-2902-0374	18B CNTRL PCB
A20B-2902-0390	6087/6088 DRIVE CARD MODULE
A20B-2902-0400	SERVO CONTROL MODULE
A20B-2902-0411	18B CNTRL PCB
A20B-2902-0420	18B CNTRL PCB
A20B-2902-0461	18B CNTRL PCB
A20B-2902-0480	18B CNTRL PCB
A20B-2902-0531	FANUC MODULE
A20B-2902-0610	6088 SPINDLE MODULE
A20B-2902-0620	6088 SPINDLE MODULE
A20B-2902-0660	PMC MODULE
A20B-2902-0700	FANUC MODULE
A20B-3900-0091	1 MB SRAM C MODULE
A20B-8001-0150	16 CNTRL PCB
A20B-8100-0137	21 I MAIN PCB
A20B-8100-0200	10.4" LCD INVERTER PCB
A20B-8100-0220	FANUC PCB

A20B-8200-0011
A20B-9000-0120
A20B-9000-0300
A20B-9001-0480
A20B-9001-0610

15B CNTRL PCB
FANUC PCB
FANUC SENSOR PCB
52/40 SUB I/O MODULE
FANUC MODULE